

LECTERN PARTS LIST AND ASSEMBLY INSTRUCTIONS

**PLEASE UNPACK YOUR LECTERN CAREFULLY
CHECK THAT THE UNIT IS COMPLETE AND UNDAMAGED**

PARTS LIST

**1 x STAND
1 x TOP
2 x CROSS FEET
4 x BOLTS
1 x ALLEN KEY**

ASSEMBLY INSTRUCTIONS

USING THE ALLEN KEY BOLT ON THE FEET STAND UNIT UPRIGHT
SLIDE ON THE TOP AND TIGHTEN LOCK KNOBS CLOCKWISE.

TO SET CLOCK AND REPLACE BATTERY

REMOVE CLOCK BACK PLATE AND CLOCK FROM UNDERSIDE
RESET USING SIDE PUSH BUTTONS
UNSCREW BATTERY COVER AND REPLACE